

Installation & Operation Instructions for UV-C / O3

[Read and Save these Instructions]

WARNING:

- ⇒ Plug unit directly into a GROUNDED wall outlet. If necessary, use only a GROUNDED extension cord.
- ⇒ Do NOT operate unit with cover removed.
- ⇒ Do NOT look directly at lamps when "on".
- ⇒ Do NOT tamper with wiring, switches etc. to compromise any internal parts of the unit.
- ⇒ Allow bulbs to cool before cleaning or replacing.
- ⇒ Do NOT use a liquid, spray, aerosol etc. cleaner on the unit. Cabinet may be lightly dusted with a clean, soft cloth.

Installation

1. Unpack unit gently from packing carton.
2. Unit may be placed on a table—or hung from a wall.
3. Mount unit Horizontally on the rubber feet - OR - Vertically on a wall using the mounting holes provided in the base of the unit. Wall-mounting screws are NOT provided with the unit.
4. Plug unit directly into grounded wall outlet.

Operation

1. Turn on fan, using the first switch located on the side of the cabinet. This switch is marked "power".
2. Each lamp is controlled by a separate switch so that you may run only one (1) of the lamps, or both of them together. There is a switch for each lamp located on the side of the cabinet, next to the "power" switch. Turn on one or both lamp switches as needed.
3. The "power" switch must be in the "on" position before either of the lamps will come "on". This is a safety feature to prevent internal over-heating, and to extend the life of the lamps.
4. Be sure all three switches are in the "off" position before unplugging unit from power source.



Maintenance

1. Check condition of cord and plug at least on a routine basis.
2. Unplug unit from outlet before servicing.
3. In normal operation, it is a good idea to periodically remove the cover and (using a soft cloth) lightly clean any dust accumulation off the lamps.
4. Replace lamps with genuine Air Lab Werks/HRS supplied lamps when either fails to operate. Allow a 100 "break in" period for new lamp output to stabilize.

WARNING

1. This is not a medical device.
2. Switch #1 activates the first (top) lamp
3. Switch #2 activates the second (bottom) lamp. They can be used independently or together.
4. Use of the Dual Technology lamps should be monitored routinely.
5. Ideally, use Switch #1 and Switch #2 on a 24/7 basis for full cleaning capability.
6. Contact Air Lab Werks if questions arise: 1-317-848-2745 or 2759